

## Transponder location

Sport Trucks transponder must be mounted 78" (inches) back measured from center of front wheel to center of transponder on left side. There must be no obstruction below the transponder to the ground.

Pro Stock, Late Model and Street Stocks transponder must be mounted 12" (inches) back from the center of axle tube to center of transponder on left side frame. There must be no obstruction below the transponder to the ground. See Diagram.

